

Characterization of Megahertz X-ray laser Beams by Multishot Desorption Imprints in PMMA

Vojtěch Vozda,^{1,2,*} Tomáš Burian,^{2,3} Věra Hájková,² Libor Juha,^{2,3} Hartmut Enkisch,⁴ Bart Faatz,⁵ Martin Hermann,⁴ Iwanna Jacyna,⁶ Marek Jurek,⁶ Barbara Keitel,⁵ Dorota Klinger,⁶ Rolf Loch,⁵ Eric Louis,⁷ Igor A. Makhotkin,⁷ Elke Plönjes,⁵ Karel Saksl,^{3,8} Frank Scholze,⁹ Frank Siewert,¹⁰ Ryszard Sobierajski,⁶ Sebastian Strobel,⁴ Kai Tiedtke,⁵ Sven Toleikis,⁵ Gosse de Vries,¹¹ Zdeněk Zelinger,¹² and Jaromír Chalupský^{2,†}

1) Charles University, Faculty of Mathematics and Physics, Institute of Physics, Ke Karlovu 5, CZ-121 16, Prague 2, Czech Republic, 2) Institute of Physics, Czech Academy of Sciences, Na Slovance 2, 182 21 Prague 8, Czech Republic, 3) Institute of Plasma Physics, Czech Academy of Sciences, Za Slovankou 3, 182 00 Prague 8, Czech Republic, 4) Carl Zeiss SMT GmbH, Rudolf-Eber-Strasse 2, 73447 Oberkochen, Germany, 5) Deutsches Elektronen-Synchrotron DESY, Notkestrasse 85, Hamburg, Germany, 6) Institute of Physics, Polish Academy of Sciences, Al. Lotników 32/46, Warsaw, PL-02-668, Poland 7) MESA + Institute for Nanotechnology, University of Twente, The Netherlands, 8) Institute of Materials Research, Slovak Academy of Sciences, 040 01 Kosice, Slovak Republic, 9) Physikalisch-Technische Bundesanstalt, Abbestr. 2-12, Berlin, 10587, Germany, 10) Helmholtz Zentrum Berlin für Materialien und Energie, Albert-Einstein-Str. 15, Berlin, 12489, Germany, 11) ASML Netherlands B.V., P.O. Box 324, Veldhoven, 5500 AH, The Netherlands, 12) J. Heyrovský Institute of Physical Chemistry, Czech Academy of Sciences, Dolejškova 2155/3, 182 23 Praha 8, Czech Republic

INTRODUCTION

- Here we present the first characterization of defocused MHz 13.5-nm beam (FLASH) using method of multi-pulse desorption imprints to PMMA [1].
- Diagnostics of intense FEL X-ray pulses is important for:
 - experimental works
 - beamline optics (overheating damage) [2]
- Material removal is not linearly proportional to total dose delivered by multiple pulses (direct beam fluence profile recovery from desorption imprint is not possible).
- We have developed a NoReFry algorithm which calculates the material response function and so the correct beam fluence profile.

RESULTS

- The NoReFry algorithm was applied to WLI data obtained from ablation (34 profiles) and MHz desorption (8 profiles) imprints.




Figure: Retrieved fluence scans and ablation contour areas (solid circles) measured from Nomarski images. The error bar was obtained from the NoReFry.




Figure: Maximum depths of imprints and recovered response functions fitted by a theoretical desorption response function model [4].





Figure: WLI depth profiles of ablation and desorption imprints. Threshold character of ablation process is clearly visible in the left image.

Figure: Corresponding beam profiles recovered using calibration curves (i.e. inverse response functions).

EXPERIMENT



- Experimental data from BL2 at the FLASH [3] (100 uJ, 13.5 nm, 100 fs)
- Ablation imprints: single-shot operation (1 pulse from train)
- MHz desorption imprints: open shutter regime (deposition of multiple pulse on the same spot)


Ablation imprints

- Single-shot induces large damage.
- One imprint provides an iso-fluence contour.
- Fluence profile can be obtained from multiple imprints at different attenuation levels.
- Low-intensity wings below the damage threshold remain unexplored.

Desorption imprints


- Accumulation of multiple shots at the same spot.
- Energy of each shot is below the ablation damage threshold.
- Fluence profile can be obtained from one single imprint (depth monotonously increases with deposited dose).
- Calibration curve (response function) must be known!

Figure: Nomarski images of ablation imprints (at different attenuation levels) and desorption imprints (different number of deposited pulses).



Non-linear Response Function Recovery (NoReFry)

- Aim:** Extraction of the calibration curve (dependence of depth on total absorbed dose) from multiple desorption imprints
- Two assumptions:** 1) Response function monotonically increases with accumulated dose 2) Iso-depth contour coincides with the beam iso-dose contour of the same area



Top: Schematics of the algorithm showing a calibration curve and fluence scan recovery from two desorption imprints.

Left: The algorithm convergence is very fast and stable solution is found within tens of iteration loops.

Top right: Matrix composed from 7 imprint profiles.

CONCLUSION

- We have developed a method to reconstruct beam profile from desorption imprints regardless of repetition rate.
- NoReFry is applicable wherever the response function monotonically but non-linearly increases with the deposited dose. (e.g. fluorescence signal acquired from an exposed LiF crystal, luminescence signal from a saturating Ce:AYG screen)
- Effect of the 3rd harmonic, intrinsically present in each FEL spectrum, can be suppressed by a proper choice of attenuators.
- PMMA could be used as an absolutely calibrated dosimeter. More information about this work will be available in [5].

REFERENCES

- J. Chalupský, et al. PR Appl. 4 (2015)
- R. Sobierajski, et al. Opt. Exp. 24 (2016)
- V. Ayvazyan, et al., PRL 88 (2002)
- T. Burian, et al., PR Appl. (submitted)
- V. Vozda, et al., PR Appl. (submitted)